



### TRANE M & R MODEL WIRING DIAGRAMS


#### 6 LEAD SINGLE VOLTAGE CRHR 500,800



PART WINDING START




FULL WINDING START - 3 WIRE




FULL WINDING START - 6 WIRE


#### 6 LEAD SINGLE VOLTAGE CRHR 400 & ALL CRHM





FULL WINDING START - 6 WIRE




FULL WINDING START - 3 WIRE



PART WINDING START




CRHR 500,800




CRHR 400 & ALL CRHM


#### TRANE DUAL VOLTAGE (208-230/460) CRHR 400 & ALL CRHM



208-230 VOLTS FULL WINDING START



208-230 VOLTS PART WINDING START



460 VOLTS FULL WINDING START

NOTE:  
DUAL VOLTAGE  
COMPRESSORS  
CANNOT BE  
OPERATED ON 480  
VOLTS PART  
WINDING START